

MAESTRO


Touch Screen, Single Channel, Power & Energy Monitor

MULTIPLE LANGUAGES



* Every language may not be available yet

CONNECTIVITY



ACCESSORIES



Additional 9V Power Supply
(Model Number: 200960)



Battery Pack
(Model Number: 201013)



USB, RS-232, External Trigger &
Analog Out Cables



Protective Pouch
(Model Number: 200128)



Pelican Carrying Case

KEY FEATURES

- 1. READS ALL HEADS**
 - Power: Thermopiles, Photo Detectors and Pyroelectrics
 - Energy: Thermopiles (in single shot mode), Photo Detectors and Pyroelectrics
- 2. LARGE TOUCH SCREEN COLOR LCD DISPLAY**
 - 5.6in Diagonal
 - 640 x 480 Resolution
 - 18bit Color
 - FULLY Touch Screen Controls
- 3. UNIQUE ERGONOMIC DESIGN**
Great for both handheld and tabletop use, with improved rubber bands and kickstand for better stability
- 4. INTUITIVE USER INTERFACE**
Easy to navigate interface, with many display features:
 - Single or Dual Graph Display
 - Instant access to the main functions
 - Function Search tool
 - Interface available in multiple languages
- 5. USB KEY ACCESS**
Store data directly on a USB key
- 6. REAL-TIME STATISTICAL FUNCTIONS**
Max, Min, Average, Standard Deviation, RMS and PTP Stability, Pulse # and Repetition Rate
- 7. AVAILABLE OUTPUTS**
USB Key, Analog Output, RS-232, PC-USB, Ethernet

PC-GENTEC-EO SOFTWARE

UNIVERSAL

Compatible with INTEGRA detectors and MAESTRO

EASY-TO-USE

Clear and concise user interface with attractive graphics and well organized functions

SEE ALSO

ENERGY DETECTORS	38
POWER DETECTORS	58
HIGH POWER DETECTORS	94
PHOTO DETECTORS	108
THZ DETECTORS	122
OEM DETECTORS	138
LIST OF ALL ACCESSORIES	188

Watch the Introduction video available on our website at www.gentec-eo.com

MAESTRO



SPECIFICATIONS

MAESTRO

DETECTOR TYPES ALL MODELS: Thermopiles, Pyroelectrics, Photo Detectors

DISPLAY Touch Screen 5.6 in Color LCD

POWER METER SPECIFICATIONS

Power Range

Thermopile 1 μ W to 30 kW

Photo Detector 4 pW to 3 W

Monitor Accuracy 0.25 % \pm 5 μ V best scale

Statistics Current Value, Max, Min, Average, Standard Deviation, RMS & PTP Stability, Time

ENERGY METER SPECIFICATIONS

Energy Range 2 fJ to 30 kJ

Monitor Accuracy \pm 1 % best scale

Software Trigger Level 0.1 to 99.9 %, 0.1 % resolution, default 2 %

Repetition Rate 2 000 Hz / 10 000 Hz in sampling

Real Time Data Transfer (To USB key) 2 000 Hz

Statistics Current Value, Max, Min, Average, Std Dev., RMS & PTP Stability, Pulse #, Rep. Rate and Avg Power

DETECTOR COMPATIBILITY

Thermopile Average Power & Single Shot Energy

Photo Detector Average Power & Pulse Energy

Pyroelectric Pulse Energy & Average Power

GENERAL SPECIFICATIONS

Interface Languages English, German, French and Japanese

Digital Display Size 112.9 x 84.7 mm LCD - 640 x 480 pixels

Data Display Real Time, Scope, Statistics, Digital Tuning Needle and Averaging

Analog Output 0-1 Volt, Full Scale, \pm 0.5 %

Rising Edge External Trigger TTL Compatible, 2-25 V @ 0.4 mA

Serial Commands Via USB (standard), Ethernet or RS-232 (cable in option)

Internet Upgrades Via USB key

Data Storage Via USB key

Dimensions 210W x 122H x 45D mm

Weight (With Batteries) 0.67 kg

Battery Type 4 x Rechargeable 1.2 V Ni-MH AA

Battery Life 6.5 hours

External Power Supply 100/240 VAC 50-60 Hz to 9 VDC 1.66 A

ORDERING INFORMATION

Product Name MAESTRO

Product Number 201235

Specifications are subject to change without notice

MAESTRO

MONITORS

ENERGY DETECTORS

POWER DETECTORS

HIGH POWER SOLUTIONS

PHOTO DETECTORS

THZ DETECTORS

OEM DETECTORS

SPECIAL PRODUCTS

BEAM DIAGNOSTICS



HOME

Set Device:	Set all the parameters related to your MAESTRO device.
Set Measure:	Set all the parameters related to your sensor.
Display:	Set the device in Dual or Full Screen display mode and choose the display(s) you want.
Acquisition:	Set all your acquisition parameters (time, sample rate, etc.).
Startup Config:	Choose how your MAESTRO will remember your sensor settings at startup.
About:	View the main parameters and update your MAESTRO.

SET DEVICE

Use the elements in this menu to set the parameters related to your MAESTRO:



Number of Digits:	Use this menu to set the precision of the measurement.
Serial Commands:	Set compatibility with SOLO2 and use the RS-232, USB and Analog Outputs
Ethernet:	Configure the Ethernet communication protocol.
Languages:	Select the display language: English, German, Japanese or French
Recalibrate Touchscreen:	Recalibrate your touchscreen by following the simple step-by-step procedure

SET MEASURE

Use the elements in this menu to set everything related to your measurements:


Wavelength:	Select one of the standard wavelengths offered, enter a custom value and create your own list of standard wavelengths.
Range:	Set the measuring range to autoscale or a fixed scale.
Measure Mode:	Use this menu to decide what type of measurements will be displayed: average power, single shot energy, pulse-to-pulse energy, etc.
Corrections:	Enter multipliers and offsets.
Trigger Level:	Set the trigger level in 0.1% steps, from 0.1% and 99.9%.

DUAL SCREEN DISPLAY (SHOWN WITH SCOPE DISPLAY)

With the Dual Screen mode, the MAESTRO really takes full advantage of its extra-large screen! Any display mode can be used in both single or dual display mode. In dual display mode, the Real Time display takes the upper portion of the screen, while any of the other displays (Scope, Needle, Averaging or Statistics) is set on the lower portion. The display in the lower portion can be easily changed using the parameters bar with drop-down menus in the center of the screen. You can also expand one of the displays to have it in Full Screen mode using the maximize  button. Just as easily, you can go back to Dual Screen display by using the minimize  button.

MAESTRO


CE NIST*
Traceable
*Also traceable to NRC-CNRC



REAL TIME DISPLAY

This display shows the measured value in real time, with a corresponding bar graph below. The large size of the digits and high contrast of the graphics allow to see the measurement from a good distance. This mode is also always present in dual screen mode, in the upper portion of the screen.

- Very Large Digits
- Bar graph



SCOPE DISPLAY

With its line filling from the right of the screen, in a first-in/first-out manner, this display mode is a good approximation of an actual oscilloscope reading. Settings include time (x-axis) and range (y-axis). Basic statistics can also be displayed directly on the screen.


- Oscilloscope-type graph
- On-screen, real time statistics (min, max and average)
- Fully customizable x and y axis



NEEDLE DISPLAY

Exactly like an analog needle, only faster! This mode is particularly useful when tuning a laser. The Real Time value is also displayed at the top of the screen.

- Ultra-fast readings
- Great for tuning
- Real Time value at the top of the screen
- Min and Max Values hold



AVERAGING DISPLAY

This very unique mode is perfect to show the trend of a laser over time. Set the number of points per batch and let the MAESTRO identify the minimum and maximum values of every batch. A yellow curve then follows the average of each batch, displayed as bars on the screen. The wider the difference between the white and blue portions of a bar (corresponding to the min and max values), the more unstable your laser is.

- Calculates the min, max and average values of batches of measurements
- Perfect to check laser stability over time